

- In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an inspection every 12 months and after any exceptional event in the life of the product.
 - PPE inspection should be conducted with the manufacturer's Instructions for Use.
- Download the instructions at [PETZL.COM](https://www.petzl.com).



FRAME-LOADED ROPE CLAMP

User information

Surname

Address

Identifier

PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

Manufacturer: Petzl, ZI Cidex 105A - 38920 Crolles - France

<input checked="" type="radio"/> Good condition (G)	<input type="radio"/> To monitor (TM)	<input type="radio"/> To repair (TR)	<input type="radio"/> Do not use, retire (R)	<input type="radio"/> N/A Not applicable
---	---------------------------------------	--------------------------------------	--	---

1. Known product history

Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...):

☒ ☐ ☐ ☐ ☐ N/A

2. Preliminary observations

- Verify the presence and legibility of the serial number and the CE mark.
- Verify that the product lifetime has not been exceeded.
- Compare with a new device to verify there are no modifications or missing elements.

☐ ☐ ☐ ☐ ☐

3. Checking the condition of the frame

- Check the condition of the frame (marks, wear, cracks, deformation, corrosion...).
- Check the condition of the attachment holes (marks, deformation, cracks, corrosion...).
- Check for wear caused by rope running through the device.
- For the TIBLOC, check that all teeth are present and check their state of wear. The teeth must not be fouled. If necessary, clean them with a brush.
- For CROLLs manufactured after February 2017, check that the wear indicator is not visible.

☐ ☐ ☐ ☐ ☐

4. Checking the cam (only on BASIC, CROLL, ASCENSION, ASCENTREE)

- Check the condition of the cam (marks, deformation, cracks, corrosion). Check that all teeth are present and check their state of wear. The teeth must not be fouled. If necessary, clean them with a brush.
- Check the condition of the cam axle and rivet (marks, deformation, cracks, corrosion...).
- Check the cam's rotation and the effectiveness of the return spring.

☐ ☐ ☐ ☐ ☐

5. Checking the safety catch (only on BASIC, CROLL, ASCENSION, ASCENTREE)

- Check the condition of the safety catch and its axle (marks, deformation, cracks, corrosion...).
- Check the effectiveness of the safety catch return spring.
- Verify that the safety catch is able to hold the cam open.

☐ ☐ ☐ ☐ ☐

6. Function check

- Verify that the rope clamp slides along the rope in one direction and locks in the other direction.

☐ ☐ ☐ ☐ ☐

Comments (detail here any defects found on the product and accomplished tasks)

VERDICT

- ☐ Product **fit** to remain in service
- ☐ Product **unfit** to remain in service

Inspected by

Company

Date Next inspection date